

RAMAIR

Fitting instructions for

TI-385-BK

Audi RS3 with 2.5 TFSI (8V Pre-Facelift) - CZGB engine only



BEFORE STARTING ANY WORK ON THE VEHICLE PLEASE ENSURE THAT THERE ARE NO EXISTING ENGINE MANAGEMENT ISSUES.

IT IS RECOMMENDED THAT YOU READ AND UNDERSTAND THESE INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING THE INSTALLATION.

IF YOU ARE AT ALL UNSURE ABOUT ANY ASPECT OF THE INSTALLATION PROCESS, PLEASE CONTACT RAMAIR FILTERS BEFORE PROCEEDING.

IRREVERSIBLE MODIFICATION (CUTTING, GRINDING, BENDING, GLUING, ETC) OF ANY COMPONENT OF THE KIT IS NOT REQUIRED FOR INSTALLATION TO A STANDARD VEHICLE, DOING SO MAY AFFECT YOUR WARRANTY.

KIT CONTENTS

QTY	PART NUMBER	DESCRIPTION
1	HP-385-BK	Pleated Air Filter
1	RAMSIL-385-BK	Heatshield Assembly
1	RSC90BK	RH Lid Plate Assembly

FITTING KIT CONTENTS

QTY	PART NUMBER	DESCRIPTION
1	WD090W2	Hose Clamp
3	WD100W2	Hose Clamp
2	STICKER	Sticker

FITTING INSTRUCTIONS**01**

Remove the flexible hose by releasing the spring clamps.

**02**

Remove the two bolts holding the intake pipe in position. Then remove the pipe and rubber coupler.

**03**

Loosely assemble the pipe and silicone with the hose clamps. Install the assembly, adjusting the pipework to have suitable clearance around the HPFP, before tightening the clamps.

